



# *CAMRY*

*Gasoline-Electric*

*Hybrid Synergy Drive*

## *HYBRID VEHICLE DISMANTLING MANUAL*



**AVV50 Series**

This information is intended for use by professional dismantlers' only – Toyota New Zealand TNZ its officers, employees, agents, contractors, partners or suppliers accept no liability whatsoever for any loss, damage, liability or cost of any kind (whether in contract, tort (including negligence) or otherwise) arising directly or indirectly out of the use of this information.

## Foreword

This guide was developed to educate and assist dismantlers in the safe handling of Toyota Camry gasoline-electric hybrid vehicles. Camry hybrid dismantling procedures are similar to other non-hybrid Toyota vehicles with the exception of the high voltage electrical system. It is important to recognize and understand the high voltage electrical system features and specifications of the Toyota Camry hybrid, as they may not be familiar to dismantlers.

High voltage electricity powers the A/C compressor, electric motor, generator, and inverter/converter. All other conventional automotive electrical devices such as the headlights, radio, and gauges are powered from a separate 12 Volt auxiliary battery. Numerous safeguards have been designed into the Camry hybrid to help ensure the high voltage, approximately 244.8 Volt, Nickel Metal Hydride (NiMH) Hybrid Vehicle (HV) battery pack is kept safe and secure in an accident.

The NiMH HV battery pack contains sealed batteries that are similar to rechargeable batteries used in some battery operated power tools and other consumer products. The electrolyte is absorbed in the cell plates and will not normally leak out even if the battery is cracked. In the unlikely event the electrolyte does leak, it can be easily neutralized with a dilute boric acid solution or vinegar.

High voltage cables, identifiable by orange insulation and connectors, are isolated from the metal chassis of the vehicle.

Additional topics contained in the guide include:

- Toyota Camry hybrid identification.
- Major hybrid component locations and descriptions.

By following the information in this guide, dismantlers will be able to handle Camry hybrid-electric vehicles as safely as the dismantling of a conventional non-hybrid automobile.

For additional information contact 0800 TOYOTA or your local Toyota dealer.

© 2011 Toyota Motor Corporation

All rights reserved. This book may not be reproduced or copied, in whole or in part, without the written permission of Toyota Motor Corporation.

# Table of Contents

<b><u>About the Camry Hybrid</u></b> .....	<b>1</b>
<b><u>Camry Hybrid Identification</u></b> .....	<b>2</b>
Exterior .....	3
<b><u>Camry Hybrid Identification (Continued)</u></b> .....	<b>4</b>
Interior.....	4
Engine Compartment.....	5
<b><u>Hybrid Component Locations &amp; Descriptions</u></b> .....	<b>6</b>
Specifications.....	7
<b><u>Hybrid Synergy Drive Operation</u></b> .....	<b>8</b>
Vehicle Operation.....	8
<b><u>Hybrid Vehicle (HV) Battery Pack and Auxiliary Battery</u></b> .....	<b>9</b>
HV Battery Pack.....	9
Components Powered by the HV Battery Pack.....	9
HV Battery Pack Recycling .....	10
Auxiliary Battery .....	10
<b><u>High Voltage Safety</u></b> .....	<b>11</b>
High Voltage Safety System .....	11
Service Plug Grip .....	12
<b><u>Precaution to be observed when dismantling the vehicle</u></b> .....	<b>13</b>
Necessary Items .....	13
<b><u>Spills</u></b> .....	<b>14</b>
<b><u>Dismantling the vehicle</u></b> .....	<b>14</b>
<b><u>Removal of HV battery</u></b> .....	<b>19</b>
HV Battery Caution Label .....	33



## About the Camry Hybrid


The Camry hybrid continues into its 2<sup>nd</sup> generation as a gasoline-electric hybrid vehicle. Hybrid Synergy Drive means that the vehicle contains a gasoline engine and electric motors for power. The two hybrid power sources are stored on board the vehicle:

1. Gasoline stored in the fuel tank for the gasoline engine.
2. Electricity stored in a high voltage Hybrid Vehicle (HV) battery pack for the electric motor.

The result of combining these two power sources is improved fuel economy and reduced emissions. The gasoline engine also powers an electric generator to recharge the battery pack; unlike a pure all electric vehicle, the Camry hybrid never needs to be recharged from an external electric power source.

Depending on the driving conditions one or both sources are used to power the vehicle. The following illustration demonstrates how the Camry hybrid operates in various driving modes.

- ❶ During light acceleration at low speeds, the vehicle is powered by the electric motor. The gasoline engine is shut off.
- ❷ During normal driving, the vehicle is powered mainly by the gasoline engine. The gasoline engine also powers the generator to recharge the battery pack.
- ❸ During full acceleration, such as climbing a hill, both the gasoline engine and the electric motor power the vehicle.
- ❹ During deceleration, such as when braking, the vehicle regenerates the kinetic energy from the wheels to produce electricity that recharges the battery pack.
- ❺ While the vehicle is stopped, the gasoline engine and electric motor are off, however the vehicle remains on and operational.




## Camry Hybrid Identification

In appearance, the 2012 model Camry hybrid is a 4-door sedan. Exterior, interior, and engine compartment illustrations are provided to assist in identification.

The alphanumeric 17 character Vehicle Identification Number (VIN) is provided under the right side front seat and left side door pillar.

Example VIN: 4T1BD1FK0CU001001


A Camry hybrid is identified by the first 8 alphanumeric characters **4T1BD1FK**.



## Camry Hybrid Identification (Continued)

### Exterior

- ❶ **HYBRID** and  logo on the trunk lid.
- ❷ **CAMRY** logo on the left side of the trunk lid.
- ❸ **HYBRID** logo on each front fender.



Exterior Left Side View



Exterior Front View



Exterior Rear View




Exterior Rear and Left Side View



## Camry Hybrid Identification (Continued)

### Engine Compartment

- ⑤ 2.5-liter aluminum alloy gasoline engine.
- ⑥ Logo on the plastic engine cover.
- ⑦ Orange colored high voltage power cables.



## Hybrid Component Locations & Descriptions


Component	Location	Description
12 Volt ❶ Auxiliary Battery	Right Side of Trunk	A lead-acid battery that supplies power to the low voltage devices.
Hybrid ❷ Vehicle (HV) Battery Pack	Trunk, Mounted to Cross Member behind Rear Seat	244.8 Volt Nickel Metal Hydride (NiMH) battery pack consisting of 34 low voltage (7.2 Volt) modules connected in series.
Power ❸ Cables	Undercarriage and Engine Compartment	Orange colored power cables carry high voltage Direct Current (DC) between the HV battery pack, inverter/converter, and A/C compressor. These cables also carry 3-phase Alternating Current (AC) between the inverter/converter, electric motor, and generator.
Inverter/Converter ❹	Engine Compartment	Boosts and inverts the high voltage electricity from the HV battery pack to 3-phase AC electricity that drives the electric motors. The inverter/converter also converts AC electricity from the electric generator and electric motors (regenerative braking) to DC that recharges the HV battery pack.
Gasoline ❺ Engine	Engine Compartment	Provides two functions: 1) Powers vehicle. 2) Powers generator to recharge the HV battery pack. The engine is started and stopped under control of the vehicle computer.
Electric ❻ Motor	Engine Compartment	3-phase high voltage AC permanent magnet electric motor contained in the front transaxle. It is used to power the front wheels.
Electric ❼ Generator	Engine Compartment	3-phase high voltage AC generator that is contained in the transaxle and recharges the HV battery pack.
A/C Compressor (with Inverter) ❸	Engine Compartment	3-phase high voltage AC electrically driven motor compressor.
Fuel Tank and Fuel Line ❾	Undercarriage and Center	The fuel tank provides gasoline via a fuel line to the engine. The fuel line is routed under the center of vehicle.

\*Numbers in the component column apply to the illustrations on the following page.

# Hybrid Component Locations & Descriptions (Continued)

## Specifications

- Gasoline Engine: 158 hp (118 kW), 2.5-liter Aluminum Alloy Engine
- Electric Motors 141 hp (105 kW), Permanent Magnet Motor
- Transmission: Automatic Only (electrically controlled continuously variable transaxle)
- HV Battery: 244.8 Volt Sealed NiMH-Battery
- Curb Weight: 3,483 lbs/1,580 kg
- Fuel Tank: 17.2 gals/65.0 liters
- Frame Material: Steel Unibody
- Body Material: Steel Panel
- Seating Capacity: 5 standard



## Hybrid Synergy Drive Operation


Once the **READY** indicator is illuminated in the instrument cluster, the vehicle may be driven. However, the gasoline engine does not idle like a typical automobile and will start and stop automatically. It is important to recognize and understand the **READY** indicator provided in the instrument cluster. When illuminated, it informs the driver that the vehicle is on and operational even though the gasoline engine may be off and the engine compartment is silent.

### Vehicle Operation

- With the Camry hybrid, the gasoline engine may stop and start at any time while the **READY** indicator is on.
- Never assume that the vehicle is shut off just because the engine is off. Always look for the **READY** indicator status. The vehicle is shut off when the **READY** indicator is off.

The vehicle may be powered by:

1. The electric motor only.
2. A combination of both the electric motor and the gasoline engine.



## Hybrid Vehicle (HV) Battery Pack and Auxiliary Battery

The Camry hybrid features a high voltage Hybrid Vehicle (HV) battery pack that contains sealed Nickel Metal Hydride (NiMH) battery modules.

### HV Battery Pack

- The HV battery pack is enclosed in a metal case and is rigidly mounted to the trunk floor pan cross member behind the rear seat. The metal case is isolated from high voltage and concealed by carpet in the cabin area.
- The HV battery pack consists of 34 low voltage (7.2 Volt) NiMH battery modules connected in series to produce approximately 244.8 Volts. Each NiMH battery module is non-spillable and in a sealed case.
- The electrolyte used in the NiMH battery module is an alkaline mixture of potassium and sodium hydroxide. The electrolyte is absorbed into the battery cell plates and will not normally leak, even in a collision.
- In the unlikely event that the battery pack is overcharged, the modules vent gases directly outside the vehicle through a vent hose.

	General
Battery pack voltage	244.8 V
Number of NiMH battery modules in the pack	34
NiMH battery module voltage	7.2 V
NiMH battery module dimensions	11 x 4.6 x 4.6 in (285 x 0.8 x 117.8 mm)
NiMH module weight	2.3 lbs (1.04 kg)
NiMH battery pack dimensions	35.8 x 19.1 x 12.5 in (909 x 486 x 317 mm)
NiMH battery pack weight	107 lbs (49 kg)

### Components Powered by the HV Battery Pack

- Electric Motor
- Inverter/Converter Motor
- Power Cables
- A/C Compressor
- Electric Generator


## Hybrid Vehicle (HV) Battery Pack and Auxiliary Battery (Continued)

### HV Battery Pack Recycling

- The HV battery pack is recyclable. Contact either your Toyota Distributor as mentioned on HV battery Caution Label (see page 26) or the nearest Toyota dealer.

### Auxiliary Battery

- The Camry hybrid also contains a lead-acid 12 Volt battery. This 12 Volt auxiliary battery powers the vehicle electrical system similar to a conventional vehicle. As with other conventional vehicles, the auxiliary battery is grounded to the metal chassis of the vehicle.
- The auxiliary battery is located in the trunk. It is concealed by the deck board and auxiliary box on the right side in the rear quarter panel well.



## High Voltage Safety

The HV battery pack powers the high voltage electrical system with DC electricity. Positive and negative orange colored high voltage power cables are routed from the battery pack, under the vehicle floor pan, to the inverter/converter. The inverter/converter contains a circuit that boosts the HV battery voltage from 244.8 to 650 Volts DC. The inverter/converter creates 3-phase AC to power the motors. Power cables are routed from the inverter/converter to each high voltage motor (electric motor, electric generator, and A/C compressor). The following systems are intended to help keep occupants in the vehicle and emergency responders safe from high voltage electricity:

### High Voltage Safety System

- A high voltage fuse ❶\* provides short circuit protection in the HV battery pack.
- Positive and negative high voltage power cables ❷\* connected to the HV battery pack are controlled by 12 Volt normally open relays ❸\*. When the vehicle is shut off, the relays stop electricity flow from leaving the HV battery pack.



#### **WARNING:**

- ***The high voltage system may remain powered for up to 10 minutes after the vehicle is shut off or disabled. To prevent serious injury or death from severe burns or electric shock, avoid touching, cutting, or opening any orange high voltage power cable or high voltage component.***


- Both positive and negative power cables ❷\* are insulated from the metal chassis, so there is no possibility of electric shock when touching the metal chassis.
- A ground-fault monitor continuously monitors for high voltage leakage to the metal chassis while the vehicle is running. If a malfunction is detected, the hybrid vehicle computer ❹\* will illuminate the master warning light  in the instrument cluster and indicate “CHECK HYBRID SYSTEM” on the multi-information display.
- The HV battery pack relays will automatically open to stop electricity flow in a collision sufficient to activate the SRS.

\*Numbers apply to the illustration on the following page.


## High Voltage Safety (Continued)

### Service Plug Grip

- The high-voltage circuit is cut by removing the service plug grip (see page 15).



High Voltage Safety System – Vehicle Shut Off (**READY-OFF**)



High Voltage Safety System – Vehicle On and Operational (**READY-ON**)

## Precaution to be observed when dismantling the vehicle



### **WARNING:**

- *The high voltage system may remain powered for up to 10 minutes after the vehicle is shut off or disabled. To prevent serious injury or death from severe burns or electric shock, avoid touching, cutting, or opening any orange high voltage power cable or high voltage component.*

## Necessary Items

- Protective clothing such as insulated gloves (electrically insulated), rubber gloves, safety goggles, and safety shoes.
- Insulating tape such as electrical tape that has a suitable electrical insulation rating.
- Before wearing insulated gloves, make sure that they are not cracked, ruptured, torn, or damaged in any way. Do not wear wet insulated gloves.
- An electrical tester that is capable of measuring DC 750 Volts or more.

## Spills

The Camry hybrid contains the same common automotive fluids used in other non-hybrid Toyota vehicles, with the exception of the NiMH electrolyte used in the HV battery pack. The NiMH battery electrolyte is a caustic alkaline (pH 13.5) that is damaging to human tissues. The electrolyte, however, is absorbed in the cell plates and will not normally spill or leak out even if a battery module is cracked. A catastrophic crash that would breach both the metal battery pack case and a metal battery module would be a rare occurrence.

A caustic alkaline is at the opposite end of the pH scale from a strong acid. A safe (neutral) substance is approximately in the middle of this scale. Adding a weak acidic mixture, such as a dilute boric acid solution or vinegar, to the caustic alkaline electrolyte will cause the electrolyte to be neutralized. This is similar but opposite to the use of baking soda to neutralize a lead-acid battery electrolyte spill.

A Toyota Material Safety Data Sheets (MSDS) is attached to this document.

- Handle NiMH electrolyte spills using the following Personal Protective Equipment (PPE):
  - Splash shield or safety goggles. A fold down face shield is not acceptable for acid or electrolyte spills.
  - Rubber, latex or nitrile gloves.
  - Apron suitable for alkaline.
  - Rubber boots.
- Neutralize NiMH electrolyte.
  - Use a boric acid solution or vinegar.
  - Boric acid solution - 800 grams boric acid to 20 liters water or 5.5 ounces boric acid to 1 gallon of water.

## Dismantling the vehicle


The following 2 pages contain general instructions for use when working on a Camry hybrid. Read these instructions before proceeding to the HV battery removal instructions on page 18.




### **WARNING:**

- ***The high voltage system may remain powered for up to 10 minutes after the vehicle is shut off or disabled. To prevent serious injury or death from severe burns or electric shock, avoid touching, cutting, or opening any orange high voltage power cable or any high voltage component.***

1. Shut off the ignition (**READY** indicator is off).  
Then disconnect the cable from the auxiliary battery negative (-) terminal.
  - (1) Remove the 3 deck boards.
  - (2) Remove the auxiliary boxes.
  - (3) Disconnect the battery negative terminal.




2. Remove No. 8 hybrid vehicle battery shield panel.
  - (1) Remove the 2 nuts and No. 8 hybrid vehicle battery shield panel.
3. Remove the service plug grip.



**Caution:**

**Wear insulated gloves for the following 3 steps.**


- (1) Slide the handle of the service plug grip to the right.
- (2) Raise the release handle of the service plug grip
- (3) Remove the service plug grip.
- (4) Apply insulating tape to the socket of the service plug grip to insulate it.




4. Carry the removed service plug grip in your pocket to prevent other staff from accidentally reinstalling it while you are dismantling the vehicle.
5. Make other staff aware that a high-voltage system is being dismantled by using the following sign: CAUTION: HIGH-VOLTAGE. DO NOT TOUCH (see page 17).
6. If the service plug grip cannot be removed due to damage to the vehicle, remove the **IG2 MAIN** fuse (25A).

**Caution:**

**This operation shuts off the HV system. Be sure to wear insulated gloves because high voltage is not shut off inside the HV battery. When it is possible to remove the service plug grip, remove it and continue the procedure.**



7. After disconnecting or exposing a high-voltage connector or terminal, insulate it immediately using insulating tape. Before disconnecting or touching a bare high-voltage terminal, wear insulated gloves.
8. Check the HV battery and nearby area for leakage. If you find any liquid, it may be strong alkaline electrolyte. Wear rubber gloves and goggles and neutralize the liquid using a saturated boric acid solution or vinegar. Then wipe up the liquid using waste rags etc.
9. If the electrolyte comes into contact with your skin, wash the skin immediately using a saturated boric acid solution or a large amount of water. If the electrolyte adheres to any article of clothing, take the clothing off immediately.
10. If the electrolyte comes into contact with your eye(s), call out loudly for help. Do not rub your eye(s). Instead, wash the eye(s) with a dilute boric acid solution or a large amount of water and seek medical care.
11. With the exception of the HV battery, remove parts by following procedures which are similar to conventional Toyota vehicles. For the removal of the HV battery, refer to the following pages.





Person in charge: \_\_\_\_\_

**CAUTION:**  
**HIGH-VOLTAGE.**  
**DO NOT TOUCH.**

**CAUTION:**  
**HIGH-VOLTAGE.**  
**DO NOT TOUCH.**

Person in charge: \_\_\_\_\_

When performing work on the HV system, fold this sign and  
put it on the roof of the vehicle.


## Removal of HV battery




### **WARNING:**

- **Be sure to wear insulated gloves when handling high-voltage parts.**
- **Even if the vehicle is shut off and the relays are off, be sure to remove the service plug grip before performing any further work.**
- **Power remains in the high voltage electrical system for 10 minutes even after the HV battery pack is shut off because the circuit has a condenser that stores power.**
- **Make sure that the tester reading is 0 V before touching any high-voltage terminals which are not insulated.**
- **The SRS may remain powered for up to 90 seconds after the vehicle is shut off or disabled. To prevent serious injury or death from unintentional SRS deployment, avoid cutting the SRS components.**

1. SHUT OFF IGNITION (**READY** indicator is off)
2. REMOVE LUGGAGE TRIM SERVICE HOLE COVER




3. REMOVE 12 V AUXILIARY BATTERY
  - (1) Disconnect the cable from the auxiliary battery negative (-) terminal.
  - (2) Disconnect the cable from the auxiliary battery positive (+) terminal.
  - (3) Remove the 12 volt auxiliary battery.



4. REMOVE LUGGAGE COMPARTMENT FLOOR MAT
5. REMOVE SPARE WHEEL COVER ASSEMBLY


6. REMOVE LUGGAGE COMPARTMENT FRONT TRIM COVER

- (1) Disengage the 8 fasteners.
- (2) Disengage the 3 claws and remove the luggage compartment front trim cover.



7. REMOVE NO. 8 HYBRID VEHICLE BATTERY SHIELD PANEL

- (1) Remove the 2 nuts and No. 8 hybrid vehicle battery shield panel.




8. REMOVE SERVICE PLUG GRIP

**Caution:**

**Wear insulated gloves for the following 3 steps.**

- (1) Slide the handle of the service plug grip.
- (2) Raise the release handle of the service plug grip as shown in the illustration below.
- (3) Remove the service plug grip.
- (4) Apply insulating tape to the socket of the service plug grip to insulate it.




## 9. REMOVE CONNECTOR COVER ASSEMBLY

**Caution:**

**Wear insulated gloves.**

- (1) Remove the 2 bolts and connector cover assembly.



## 10. CHECK TERMINAL VOLTAGE

- (1) Check voltage at the terminals in inspection point in the power control unit.

**Caution:**

**Wear insulated gloves.**


**To prevent serious injury or death, do not proceed with dismantling of the HV system until the voltage at the terminals in the inspection point is 0 V.**

**Standard voltage: 0 V**

**Hint:**


Set the tester to the DC 750 Volts range to measure the voltage.

This inspection is performed to verify that it is safe to remove the HV battery.




## 11. REMOVE REAR FLOOR FINISH PLATE

- (1) Remove the 5 clips.




- (2) Disengage the 4 clips and remove the rear floor finish plate.




12. REMOVE NO. 1 LUGGAGE  
COMPARTMENT TRIM HOOK

- (1) Push the 2 pins and remove the 2 No. 1 luggage compartment trim hooks.




13. REMOVE LUGGAGE COMPARTMENT  
INNER TRIM COVER LH

- (1) Remove the 3 clips.
- (2) Disengage the fastener and remove the luggage compartment inner trim cover LH.



14. REMOVE LUGGAGE COMPARTMENT  
INNER TRIM COVER RH


- (1) Remove the 3 clips.
- (2) Disengage the fastener and remove the luggage compartment inner trim cover RH.



## 15. REMOVE REAR SEAT CUSHION

### ASSEMBLY


- (1) Disengage the hook of the seat cushion from the vehicle body as shown in the illustration.
- (2) Remove the rear seat cushion assembly.



## 16. REMOVE REAR SEATBACK ASSEMBLY RH


- (1) Disengage the 3 fasteners as shown in the illustration.

- (2) Remove the 2 bolts and rear seatback assembly RH.




## 17. REMOVE NO. 2 ROOM PARTITION COVER

- (1) Using a moulding remover, disengage the claw and guide, and remove the No. 2 room partition cover.




## 18. REMOVE REAR SEATBACK ASSEMBLY LH


- (1) Pull the cable to relock the seatback lock and fold the rear seatback assembly LH forward.



- (2) Disengage the 2 fasteners as shown in the illustration.




- (3) Remove the 2 bolts and rear seatback assembly LH.




#### 19. REMOVE REAR SIDE SEATBACK ASSEMBLY LH

- (1) Disconnect each connector.  
(2) Remove the 2 bolts.  
(3) Disengage the hook and remove the rear side seatback assembly LH.



#### 20. REMOVE REAR SIDE SEATBACK ASSEMBLY RH


- (1) Disconnect each connector.  
(2) Remove the 2 bolts.  
(3) Disengage the hook and remove the rear side seatback assembly RH.



#### 21. CUT REAR SEAT BELT LH, REAR SEAT BELT RH AND REAR SEAT BELT CENTER

22. REMOVE CHILD RESTRAINT SEAT ANCHOR BRACKET SUB-ASSEMBLY LH

- (1) Remove the 2 nuts and child restraint seat anchor bracket sub-assembly LH.




23. DISCONNECT REAR DOOR OPENING TRIM WEATHERSTRIP LH AND RH


24. REMOVE ROOF SIDE INNER GARNISH LH AND RH

25. REMOVE CENTER STOP LIGHT SET

- (1) Slide the center stop light set in the order and directions shown by the arrows in the illustration while pushing it towards the rear of the vehicle to disengage the 4 claws.




- (2) Turn the center stop light set 180 degrees as shown by the arrow in the illustration.
- (3) Disconnect the connector and remove the center stop light set.




26. REMOVE PACKAGE TRAY TRIM PANEL ASSEMBLY

- (1) Using pliers, disengage the 3 clips from inside the luggage compartment as shown in the illustration.
- (2) Disengage the 5 guides.
- (3) Pass the 3 rear seat belt floor anchors through the package tray trim panel assembly then remove the package tray trim panel assembly.




## 27. REMOVE ROOM PARTITION BOARD

- (1) Using a clip remover, remove the clip.
- (2) Disengage the 5 claws and clip, and remove the room partition board LH.




- (3) Using a clip remover, remove the 4 clips.
- (4) Disengage the 4 clips, and remove the room partition board RH.



## 28. REMOVE NO. 1 HYBRID BATTERY INTAKE DUCT

- (1) Remove the 3 clips and No. 1 hybrid battery intake duct.



## 29. REMOVE NO. 4 HYBRID BATTERY SHIELD PANEL

### **Caution:**



**Wear insulated gloves for the following 2 steps.**

- (1) Remove the 3 clips and No. 1 hybrid battery intake duct.

### **Hint:**

Insert the projecting part of the service plug grip and turn the button of the battery cover lock striker counterclockwise to release the lock.

- (2) Remove the bolt, 2 nuts and No. 4 hybrid battery shield panel.



## 30. REMOVE NO. 4 FLOOR WIRE


### **Caution:**

**Wear insulated gloves.**

### **Notice:**


**Insulate the terminals of the removed frame wire with insulating tape.**

- (1) Disconnect the 2 connectors shown in the illustration.
- (2) Disconnect the shielded wire ground and disconnect the No. 4 floor wire.




## 31. DISCONNECT LOW VOLTAGE CONNECTOR

- (1) Disconnect the connector and clamp shown in the illustration.



- (2) Disconnect the 2 connectors.



### 32. REMOVE HV BATTERY

**Caution:**


**Wear insulated gloves.**

**Notice:**


**Since the HV battery is very heavy, 2 people are needed to remove the HV battery.**

**When removing the HV battery, do not damage the parts around it.**


- (1) Remove the 6 bolts from the HV battery.




- (2) Pull the HV battery toward the center of the luggage compartment.




- (3) Remove the 2 nuts and No. 2 hybrid vehicle battery upper cover bracket.




- (4) Remove the clip.  
(5) Disengage the 2 claws and remove the No. 2 hybrid battery intake duct.




- (6) Disconnect the connector from the battery cooling blower assembly.  
(7) Remove the 3 nuts and battery cooling blower assembly.



- (8) Turn the HV battery 180° .  
(9) Pull the HV battery together with the cardboard toward the rear of the vehicle.



(10) Using a suitable adaptor such as a rope, remove the HV battery while tilting the HV battery.



34. The HV battery pack is recyclable. Contact your Toyota distributor (if included on the HV battery caution label) or contact the nearest Toyota dealer (see the next 2 pages for samples of the HV battery caution label).

**Caution:**

**After removing the HV battery, do not reinstall the service plug grip to the HV battery.**

## HV Battery Caution Label

<b>⚠ DANGER</b>		      
<b>High Voltage Inside / Alkaline Electrolyte</b> <b>Haute tension à l'intérieur / Electrolyte alcalin</b>		<b>Ni-MH</b>
<p>Observe the following precautions when you handle this battery unit. If you do not conform to those, it may result in a fire, an electrical shock and death in the worst case. Leakage of alkaline electrolyte may cause blindness or skin problems, if alkaline electrolyte comes into contact with your eyes, skins or clothes. In event of accident, flush with water and get medical help immediately.</p> <p>● Never disassemble, convert or divert this battery unit or remove its covers. (Please have the battery serviced by your dealer or a Qualified Technician.) ● Do not dump this unit illegally. It may result in pollution, death or serious injury. ● Do not puncture or expose this unit to impact. ● Keep this unit away from a fire. ● Do not water this unit. ● Keep children away from this unit.</p> <p>Respecter les mesures de précaution suivantes lorsque vous manipulez cette batterie. Le non-respect de ces mesures peut provoquer un incendie ou une décharge électrique et entraîner la mort dans les cas les plus graves. Une fuite d'électrolyte alcalin peut entraîner la cécité ou des problèmes dermatologiques si l'électrolyte alcalin entre en contact avec les yeux, la peau ou les vêtements. En cas d'accident, rincer abondamment à l'eau et consulter immédiatement un médecin.</p> <p>● Ne jamais démonter, convertir ou dévier cette batterie, ou en déposer les couvercles. (Veillez à faire entretenir la batterie par votre concessionnaire ou un technicien qualifié.) ● Ne pas jeter cette batterie de manière illégale. Cela pourrait polluer l'environnement, provoquer de graves blessures ou entraîner la mort. ● Ne pas percer cette batterie ou l'exposer à des impacts. ● Tenir cette batterie éloignée du feu. ● Ne pas mouiller cette batterie. ● Garder hors de portée des enfants.</p>		
<b>To Qualified Technicians, Haulers, Dismantlers</b> <b>A l'attention des techniciens qualifiés, transporteurs, démonteurs</b>		
<p>Be sure to read the Repair Manual when servicing or replacing this unit. Please consult your dealer or your national distributor when hauling or dismantling this unit. Veillez à lire le manuel de réparation lors de l'entretien ou du remplacement de cette batterie. Veillez à consulter votre concessionnaire ou votre distributeur national lorsque vous transportez ou démontez cette batterie.</p>		
<b>HV Battery Recycling Information</b> <b>Informations concernant le recyclage des batteries des HV (Véhicules Hybrides):</b>		
<p>● Please transport this unit in accordance with all applicable laws. ● Consultations about replacing and disposing this battery unit are accepted in your dealer or your national distributor. ● Veillez à transporter cette batterie dans le respect des lois applicables. ● Vous pouvez consulter votre concessionnaire ou votre distributeur national pour savoir comment remplacer ou éliminer cette batterie.</p>		
		<b>D</b>